



Aluminum Competition A Frame



assembly instructions



TIP- RECOMMEND TWO OR MORE PEOPLE TO ASSEMBLE

The Competition A frame consists of 4 cartons each containing one half of each side of the A Frame. Open the cartons and lay them on a flat level surface (TIP-you can fold the cartons flat and place the rubber side down on top if them to protect the surface)



There are four L shaped connector brackets used to connect the upper and lower A frame panels together. Unscrew the bolts and free up the aluminum bars attached.



Lay the lower (yellow rubber) section below the upper (Blue rubber) section and slide the aluminum Bars into the grooves in the frame on both sides of the frame



Line up the bars with the grooves on the lower panel and Slide the upper and lower sections together



Once everything is in place and the holes line up with the exterior connector bracket. Insert screws and fasten the upper and lower sections together

Once the sections have been assembled



Install the Bar holder brackets at the top of the panels –this may require adjusting the PVC profile

**Once the panels are ready with the bar holder installed
Lay both panels end to end and insert the joiner bar**

**Once the bar has been installed with help
Roll the a frame onto its side and open it into a V shape so that it will remain on its side without support.**

Attach chains and with help on each side of the center lift and roll the frame into an upright position

